
*Necessary preliminary tasks:*


- Remove luggage compartment floor trim panel.



Remove clips (1) and fold up front luggage compartment floor trim panel (2) slightly.

*Installation:*

Make sure front luggage compartment floor trim panel (2) is correctly seated.

*Note:*

Front luggage compartment floor trim panel shown removed for purposes of clarity.

Unfasten plug connection (1) and disconnect.

Unscrew nuts (2).

Remove module (3) in direction of arrow.