51 16 400 Removing and installing or replacing sun blind at fixed side window of left or right rear door



Pull roller sun blind (1) at top towards rear and snap out spring (2) towards top with a small screwdriver.



Remove roller sun blind (1) towards inside/top.