



**51 49 017 Removing and installing/replacing trim panel for rear window frame on (inside) left or right**



Detach trim panel (1) from retainers (2) towards inside.

*Installation:*

If necessary, replace faulty retainers (2).



*Installation:*

Lugs (1) on panel (2) must not be damaged.