



BMW Workshop Manuals

THE 2015 NISSAN
QUEST®

0%
APR FINANCING
FOR UP TO 36 MONTHS
FOR WELL-QUALIFIED BUYERS

PLUS
\$1,500
Bonus Cash⁽¹⁾

ST

*More Loan!

WeatherTech
FloorLiner™



G+1

Search



Custom-Fit Protection
Shop now!

jet.com

15% off
your first 3 orders*

Save on everything for your household.

Shop Now


*Brand restrictions may apply.
Max discount \$30.
Order minimum \$35.

X Series E70 X5 3.0d (M57T2) OFFRD

[2 Repair Instructions](#) > [51 Body Equipment \(OFFRD\)](#) > [16 Mirrors-covers-ashtrays-shelves-trays](#) > 31 RA Removing And Installing_replacing Lower Glovebox Lid


51 16 372

Removing and installing/replacing lower glovebox lid



Necessary preliminary tasks:

- Remove glovebox




Close glovebox lid.

Release tab washer (1) and [remove](#) pin (2).

Installation:

Replace tab washer (1) and pin (2).




Drive out shaft (1) in direction of arrow until knurled area (2) is [exposed](#).

Pull out shaft (1) completely and remove glovebox lid.

Installation:

Check that shaft (1) is securely seated.

If necessary, fit flap fastening set.



Installation:

If necessary, replace faulty bushings (1).

Markings (2) on bushing (1) and glovebox lid (3) must line up.

RA Removing and installing/replacing lower glovebox lid
Issue status (12/2007) Valid only until next DVD is issued

BMW AG - TIS
Copyright

[2 Repair Instructions](#) > [51 Body Equipment \(OFFRD\)](#) > [16 Mirrors-covers-ashtrays-shelves-trays](#) > 31 RA Removing And Installing_replacing Lower Glovebox Lid

[Privacy Policy](#)

Donate and help keep workshop manuals
freely available.



[Other BMW Workshop Manuals](#)

[Other Makes](#)

[X Series E70 X5 3.0d \(M57T2\) OFFRD Workshop Man](#)

[1 Service Information](#)

[2 Repair Instructions](#)

[0 Maintenance And General Data](#)

[11 Engine \(M57T2\)](#)

[12 Engine Electrical System \(M57T2\)](#)

[13 Fuel System \(M57T2\)](#)

[16 Fuel Supply System \(M57T2\)](#)

[17 Cooling System \(M57T2\)](#)

[18 Exhaust System \(M57T2\)](#)

[22 Engine And Gearbox Suspension](#)

[24 Automatic Transmission \(AUT\)](#)

[26 Propeller Shaft](#)

[27 Transfer Box](#)

[31 Front Axle](#)

[32 Steering And Wheel Alignment](#)

[33 Rear Axle](#)

[34 Brakes](#)

[35 Pedals](#)

[36 Wheels With Tyres](#)

[37 Integrated Suspension Systems](#)

[41 Body \(OFFRD\)](#)

[51 Body Equipment \(OFFRD\)](#)

[0 General](#)

[11 Front Bumper](#)

[12 Rear Bumper](#)

[13 Trim, Covers, Handle Trim](#)

[14 BMW Emblems, Model Emblems](#)

[15 Bumper Strip](#)

[16 Mirrors-covers-ashtrays-shelves-trays](#)

[1 RA Calibrating Compass In Interior Rea](#)

[2 RA Cementing Of Mirror Base](#)

[Page 1619](#)

[3 RA Overview Of Storage Compartment](#)

[4 RA Removing And Installing Insert For](#)

[5 RA Removing And Installing_replacing](#)

[6 RA Removing And Installing_replacing](#)

[7 RA Removing And Installing_replacing](#)

[8 RA Removing And Installing_replacing](#)

[Page 1626](#)

[9 RA Replacing Mirror Glass For Rear-vie](#)

[Page 1628](#)

[10 RA Removing And Installing_replacing](#)

[11 RA Removing And Installing_replacing](#)

[Page 1631](#)

[12 RA Removing And Installing_replacing](#)

[13 RA Removing And Installing_replacing](#)

[Page 1634](#)

[14 RA Removing And Installing_replacing](#)

[Page 1636](#)

[Page 1637](#)

[15 RA Removing And Installing_replacing](#)

[Page 1639](#)

[Page 1640](#)

[16 RA Removing And Installing_replacing](#)

[Page 1642](#)

[Page 1643](#)

[17 RA Removing And Installing Or Repla](#)

[18 RA Removing And Installing_replacing](#)

[19 RA Removing And Installing_replacing](#)

[20 RA Removing And Installing Complete](#)

[Page 1648](#)

[21 RA Removing And Installing_replacing](#)

[22 RA Removing And Installing_replacing](#)

[Page 1651](#)

[23 RA Removing And Installing_replacing](#)

[Page 1653](#)

[24 RA Removing And Installing_replacing](#)

[Page 1655](#)

[25 RA Removing And Installing_replacing](#)

[26 RA Removing And Installing_replacing](#)

[Page 1658](#)

[27 RA Removing And Installing_replacing](#)

[28 RA Removing And Installing_replacing](#)

[Page 1661](#)

[29 RA Removing And Installing Right Gic](#)

[Page 1663](#)

[30 RA Removing And Installing_replacing](#)

[Page 1665](#)

[>>31 RA Removing And Installing_replacing](#)

[32 RA Removing And Installing_replacing](#)