

Date: 10/30/15 11:44:00
 ECU: MS430DS0
 JobStatus: OKAY
 Variant: MS430DS0

RESULT: 4 errors in error memory !

225 Reaction time NKAT-Probe BK2

Error frequency : 37
 Logistic counter: 40

VLS_MMV_MIN_UP_1	0.11	V
VLS_MMV_MAX_UP_1	0.81	V
CAT_DIAG_1	0.00	-
VLS_CYC_AFL_RATIO_MV_1	0.00	-
aufgetreten vor (rel. BZ)	9.30	h

 at the rich range to big

 Error to relevant
 Error debounce
 Error currently not available
 sporadic Error

Errorcode: E1 B2 25 28 15 A2 00 00 95 99

235 Oxygen-sensor control upstrem bank 1

Error frequency : 5
 Logistic counter: 38

VLS_MMV_MIN_UP_1	0.13	V
VLS_MMV_MAX_UP_1	0.81	V
CAT_DIAG_1	0.00	-
VLS_CYC_AFL_RATIO_MV_1	0.00	-
aufgetreten vor (rel. BZ)	7.60	h

 at the rich range to big

 Error to relevant
 Error debounce
 Error currently not available
 sporadic Error

Errorcode: EB B2 05 26 19 A1 00 00 95 AA

227 lambda contol tolerance Bank 1

Error frequency : 1
 Logistic counter: 31

N_32	1600.00	rpm
MAF	283.25	mg/stk
TCO	56.25	Grad C
LAM_MV_1	12.89	%
aufgetreten vor (rel. BZ)	5.50	h

Deviation rich

Error to relevant
Error debounce
Error currently not available
sporadic Error

Errorcode: E3 B1 01 1F 32 34 8B A1 95 BF

215 downstream sensor, active test BK1 (Probe 3)

Error frequency : 1
Logistic counter: 40

VLS_DOWN_1	0.01	V
VLS_DOWN_2	0.13	V
MAF	174.31	mg/stk
N_32	1664.00	rpm
aufgetreten vor (rel. BZ)	0.00	h

rich voltage not reached

Error to relevant
Error debounce
Error currently available
stat. Error

Errorcode: D7 72 01 28 02 19 20 34 95 F6
